



# DataMaster II

PROGRAMMING DEVICE



# DataMaster II



## AT YOUR SERVICE

DataMaster II is a general-purpose programming, setup and calibration tool for several Kemppi welding machine models.

Installing DataMaster II PC software

**NOTE!** Microsoft .Net Framework 4 or newer has to be installed on your computer before the DataMaster installation.

Install the PC software before using DataMaster II. [Download software](#)

If you are using an USB port/cable, download the device driver [here](#) (device: FT232BM).

If you are using the serial RS-323 port, no device driver installation is needed.

### How to Start:

1. After successful PC software installation, connect DataMaster II device to your computer.
2. Turn on the DataMaster II.
3. Windows detects a new device automatically and installs the driver.
4. When the installation is complete, restart the computer. The PC software will be launched automatically.

## KEY APPLICATIONS



REPAIR AND  
MAINTENANCE

[WWW.KEMPPI.COM](http://WWW.KEMPPI.COM)

---

**Kemppi** is the design leader in the arc welding industry. We are committed to boosting the quality and productivity of welding by continuous development of the welding arc and by working for a greener and more equal world. Kemppi supplies sustainable products, digital solutions, and services for professionals from industrial welding companies to single contractors. The usability and reliability of our products is our guiding principle. We operate with a highly skilled partner network covering over 70 countries to make its expertise locally available. Headquartered in Lahti, Finland, Kemppi employs close to 800 professionals in 16 countries and has a revenue of 195 MEUR in 2022.

